

The King Pro

Propane Polisher, Stripper, Buffer, & Sander



Features:

- Rugged all steel construction
- Planetary drive to eliminate shadowing and side torque
- Sealed planetary drive with synchronous belt to eliminate slip and increase durability
- Premium bearings and bearing seals throughout for durability
- Standard dust control functionality
- Standard 8 gallon water tank
- Premium German centrifugal clutch
- Adaptor port for active vacuum
- Locking easy spin-on spin-off heads for quick application change
- 330lbs head pressure
- Includes 3 sets quick change heads for stripping, polishing, and burnishing concrete
- Compatible for use with 4" ceramic or resin diamond pucks and diamond impregnated pads
- Transport wheel for easy loading and maneuvering
- Low profile - fits under 8" shelf
- Green certifications: EPA, CARB, LEED, CE, & GS-42

Specifications:

Path Size	30" (76 cm)
Engine	Kawasaki 603 cc
Centrifugal Clutch	Standard
Head Pressure	330 lbs (150 kg)
Head Size	3 ea. 10" (25 cm) Quick Change Heads
Head Speed (Clockwise)	1295 RPM
Brush Drive Speed (Clockwise)	250 RPM
Machine Weight	495 lbs (225 kg)
Height	42.25" (107 cm)
Length	47.25" (120 cm)
Width	32.75" (83 cm)
Shipping Weight*	Approx. 535 lbs (243 kg)
Machine Warranty	1 Year
Engine Warranty	2 Years / 500 Hours
Green Certifications	EPA, CARB, LEED, GS-42 Available with Blue Sky Certified Engine

Included Drive Heads:

- 3 x 10" Malgrit Strip Brush
- 3 x 10" Mighty Lok
- 3 x 10" Velcro Hook & Loop

Safety Specifications:

- Meets US Green Building Council LEED IAQ
- Credit 3.4 Requirements
- CE, CARB, EPA & GS-42 Compliant
- Low Oil Shutdown
- Safety Regulator Fuel System

Available Options:

- Auto Emissions Shut Down
- Blue Sky Certified Engine
- Kill Switch Lanyard

Corporate Office: 190 Summerhill Road * Spotswood, NJ 08884 * (888) 246-7446

www.Bio-Shine.com

www.CleaningEquipmentParts.com