

# The OmniFlex™ AutoVac™ System

The OmniFlex AutoVac is a crossover autoscrubber that cleans as well and as fast as a traditional walk-behind or ride-on autoscrubber – at a fraction of the cost!

A really simple approach to cleaner, safer floors, this system is perfect for high speed cleaning of hard surface areas, such as hallways, cafeterias, lobbies, warehouses, fitness areas and more. It's as fast and effective as an autoscrubber without the added cost or complexity, making it perfect for building service contractors and facility managers alike.

## PERFECT FOR:

Hallways  
Lobbies  
Cafeterias  
Gymnasiums  
Warehousing  
Shop Floors  
Healthcare  
Retail

Daily floor cleaning  
Stripping floors  
Finishing floors

**NOW AVAILABLE  
WITH SMART BATTERY  
TECHNOLOGY!**

Optional 100 Ft.  
Electric Cord



Universal Handle  
with Posts

Optional  
Battery Box

Self-dispensing  
Spigot with  
Adjustable Handle

28 Inch Drop Down  
Squeegee Head

Pad and Frame for  
Spreading Liquid

Vac Tank with  
Dump Hose

10 Gallon  
Fresh Water Tank



## HIGHLIGHTS

- In tests performed by a major university, both the AutoVac and an autoscrubber removed over 99% of targeted soil, while a new microfiber mop removed only 51%.
- Certified by the National Floor Safety Institute (NFSI) for providing high traction.
- Battery model cleans 20,000+ sq. ft. an hour. Corded version cleans 16,000+ sq. ft. an hour.
- Can switch between corded and battery operation in seconds.
- Very simple to learn, use and maintain.
- Breaks down for light, easy transport.
- Perfect for applications where auto-scrubbers are not practical.
- Available as a preconfigured package or as a simple, inexpensive add-on to existing OmniFlex systems.
- Includes all components necessary for a complete floor care system: cleaning, degreasing, stripping, waxing, and more.
- Easily expand capabilities by adding OmniFlex components and tools.



*Complete Cleaning  
For Healthy Results™*

# Why is OmniFlex™ AutoVac™ Better?



## Cleaning Effectiveness

In comparative tests performed by a major university, the AutoVac system removed up to 99.8% of targeted soil. This was slightly better than an autoscrubber, which removed up to 99.4%. A brand new microfiber mop only removed up to 50.9%. Ask your Kaivac representative for a full report.

## High Performance

Independent performance tests show that users can clean more than 20,000 square feet per hour with the cordless AutoVac system. Plus, most users won't have to dust mop before cleaning or trail mop after cleaning.

## Flexible Power Options

AutoVac is available in both corded and lithium-ion battery powered models for the ultimate in flexibility. The cordless capability offers maximum productivity and ease while the corded model offers extreme cost-effectiveness and robust reliability. The best part? You can switch between modes in seconds for the best of both worlds.

## Low Cost of Ownership

For most, the economics are the most compelling advantage. For starters, its initial purchase price is 10-25% of an equivalently sized autoscrubber. In many cases, it's less than the average annual maintenance costs of an autoscrubber. And, if you already own an OmniFlex, this capability is available as a simple, low cost add-on. Plus, it's gentle on floors and finish, helping to prolong finish life and reduce refinishing operations.

## Easy and Inexpensive to Maintain

The AutoVac is inexpensive and easy to maintain. That's because, with so few moving parts, very little can go wrong. And if it does, it's so easy to troubleshoot and fix, unlike most cleaning equipment. Even better, the system doesn't require a technician to maintain or fix. And in most cases, an entire unit can be reconditioned in minutes for less than the cost of a single service call.

## Multiple Modes of Operation



**Spread-and-Vac**  
Simultaneously dispense and spread cleaning solution with instant vacuum extraction.



**Spread Only**  
Extended dwell time for heavy soil, disinfection, etc.



**Vac Only**  
Vacuum removal of liquids, cleaning solution, stripper.

## OmniFlex™ AutoVac™ Includes:

### AutoVac Add-on Kit

- Hitch Assembly for Trolley-Bucket
- 28 In. Drop Down Squeegee Head
- Drop Down Frame for Spreader Pad
- 5 Microfiber Pads

### AutoVac Cordless Complete

- OmniFlex Trolley-Bucket
- OmniFlex Wet/Dry Vacuum with DC Motor
- AutoVac Add-on Kit
- Lithium-ion Smart Battery Box

### AutoVac Corded Complete

- OmniFlex Trolley-Bucket
- OmniFlex Wet/Dry Vacuum with AC Motor
- AutoVac Add-on Kit

### Optional

- 100 Ft. Electrical Cord
- Lithium-ion Smart Battery Box

## Vacuum Specifications:

Vac Tank	10 Gallons (37,85 l)
Vac Tank Cleanout	100% via Dump/Drain Hose
Vac CFM	62 cfm (1698 l/min)
Vac Motor Lift	77 inches (195,6 cm)

**BS124036 - Autovac Electric**

**BS125359 - Autovac Battery**