

## TGB 1120 & EGB 1120

### Twintec Battery Scrubbers TGB 1120 / EGB 1120 Pad Assist Walk Behind Scrubber

With 11-gallon solution and recovery tanks, the TGB 1120 and EGB 1120 are compact, easy to transport and so easy to use anyone can operate them. Both units clean up to 22,000 sq.ft./hr.

#### Key Features

- 11-gallon solution and recovery tanks
- Both units run for 3-3.5 hours but the TGB 1120 has an onboard charger and is powered by 2 maintenance-free gel batteries while the EGB 1120 has an external charger and 2 wet lead acid batteries (not included)
- They both feature a Patented flip-up head making pad or brush changes a breeze
- Fully adjustable flow rate
- Adjustable handle provides proper ergonomics for any operator
- Prolonged battery life with low-voltage shutoff
- Hour meter and battery level indicator
- Tear-away squeegee with quick-release blades for easy cleaning

#### Gel Batteries:

- Safest, most dependable batteries on the market
- Longest-life batteries on the market
- Emit 1/40 of the hydrogen gas of wet lead acid batteries
- Spill-proof and can be charged anywhere



*Patented flip-up head  
for easy pad changes*



*Maintenance-free gel  
batteries are standard  
(TGB 1120 ONLY)*



*On-board battery charger  
(TGB 1120 ONLY)*



*Inline filter captures debris*



*Control panel provides an hour meter and monitors the battery status*



*Quick-fill hose allows you to fill from a tap instead of using buckets*



**MODEL**

**TGB 1120 / EGB 1120**

Cleaning Path	20"	Noise Level dB(A)	67 dB(A)
Pad or Brush Size	20"	Working Capacity (sq. ft./hr.)	22,000
Solution/Recovery Tank	11 gal.	Run Time	3–3.5 hours
Brush Pressure	75 lbs.	Batteries (TGB 1120)	2 x 12v, 100 Ahr. (Gel)
Brush Speed	150 rpm	Batteries (EGB 1120)	2 x 12v (not included)
Brush Motor	24V, 400W	Weight (With Batteries)	277 lbs.
Vacuum Motor Power	24V, 400W	Dimensions (LxWxH)	44" x 22" x 43"