

Commercial Vacuums by Tacony Corporation

CLEANMAX™

Fast, easy, comfortable and now no limits! The CleanMax Cordless Backpack is free to clean wherever the job demands. Complete with the exceptional Deuter Aircomfort harness system, HEPA media filtration and six different cleaning attachments, the Cordless 6 quart Backpack is packed with features to tackle any cleaning situation.

- State-of-the-art lithium ion battery technology for up to 55 minutes of continuous cleaning and over 900 charge cycles
- The battery can be fully recharged in less than 2 ½ hours or can be swapped out for a fresh battery without taking the backpack off
- 5-Point adjustable harness, designed by Deuter, the world's leader in professional hiking equipment, provides unrivaled comfort for maximum productivity
- 4-Stage filtration system including a HEPA media filter cartridge for improved indoor air quality
- Includes crush-proof hose, double bend wand, carpet and floor tools, dusting brush, upholstery tool and crevice tool



Model: CMBP-CL

CORDLESS BACKPACK

SPECIFICATIONS	
Model	CMBP-CL
PERFORMANCE	
Motor	13 Amps
Battery	36 Volt Lithium Ion
CFM Average	70 CFM / 65 IOW
On/Off Switch	On the battery pack
Decibel Rating	Less than 65 dBA
Weight	19 Pounds
Tools	Crush-proof hose, double bend wand, carpet and floor tools, dusting brush, upholstery tool and crevice tool
DURABILITY	
Wand	Aluminum double bend wand
Warranty	1 Year Comprehensive
FILTRATION	
Vacuum Bag	Paper
Filter	HEPA Media



Battery Life Indicator

The power of the Cordless Backpack stays strong through the end of the battery charge. The green lights indicate how much full power battery life remains and the red light signals it's time to recharge or swap batteries.



**Deuter Aircomfort
Harness System**

Ergonomic and anatomically shaped stable hip fins and waist belt, proven to balance pack weight for maximum comfort and to keep the user cool.