

14000-Watt – Gasoline

Alternator:

- Total harmonic distortion (THD) less than 5%
- 100% copper windings

Frame:

- Reinforced 1¼-inch powder coated steel tube frame
- 13-inch flat-free tires

Components:

- Easy-access and protected control panel with magnetic circuit breakers and GFCI-protected receptacles
- Large low tone mufflers
- Easy-to-read fuel gauge
- Idle control
- Voltmeter/hour meter
- Heavy-duty industrial air cleaner

Miscellaneous:


- USDA/USFS-approved spark arrestors

Limited Warranties:

- 2 year alternator
- 3 year Honda engine

Certification:

- CSA Certified



GFCI 5-20R



NEMA L14-30R
120V/240V



NEMA 14-50R
50A



NEMA L5-30R
120VAC



GX-0005 option CS6369A
50A twist lock receptacle

GEN-14000-1MHE

The Mi-T-M 14000-watt generator is a virtual power plant. Built for industrial applications with the portability to move from one job to the next, this generator will never let you down. It's the perfect tool for professional contractors and houses.

MODEL NO.	GEN-14000-1MHE
MAX. AC OUTPUT	14000 watts
RATED AC OUTPUT	12000 watts
DISPLACEMENT/ENGINE	688cc Honda GX630 OHV with electric start - battery included
ALTERNATOR	Brushless 120V/240V, 60Hz
MAX. AMPS (120V/240V)	116.7/58.3
CONT. AMPS (120V/240V)	100.0/50.0
RECEPTACLES	(2) 120V, 20A GFCI duplex / (1) 120V, 30A twist lock (1) 120V/240V, 30A twist lock / (1) 120V/240V, 50A
CIRCUIT BREAKERS	(2) 20A toggle circuit breakers single pole / (1) 30A toggle circuit breaker, single pole / (1) 30A toggle circuit breaker, double pole / (1) 50A toggle circuit breaker, double pole
RATED SPEED	3600 RPM
DECIBEL RATING	77.5
FUEL CAPACITY	13.2 gallons
RUN TIME (AT FULL LOAD)	8.0 hours
DIMENSIONS (LxWxH)	31.5x30.5x37.5in.
SHIP WT.	568 lb.
NET WT.	508 lb.

Noise level tested at seven meters (75% load). Rating represents minimum noise level rating.

Accessories & Options:

PART NUMBER	DESCRIPTION	FITS MODEL	PART NUMBER	DESCRIPTION	FITS MODEL
32-0915	RV generator adapter	GEN-14000-1MHE	GX-0003	Skid feet	GEN-14000-1MHE
AW-6000-1002	Equipment cover	GEN-14000-1MHE	GX-0005	50-amp twist lock receptacle	GEN-14000-1MHE



190 Summerhill Rd. * Spotswood, NJ 08884
(732)-251-9506 * nconover@bio-shine.com